

10024.PLHATD

AFN
acessórios 4x4



Checklist / Manual de Montagem -
PRT.LAT.P/HI-LIFT C/AL(3PTS)PRT DEF.TD5



Checklist / Fitting Instructions -



Despiezas / Instrucciones de montaje -



1 x1

47000266




2 x1

47000269



3 x4


45000014



Prf. Cb. Sx. M8x25

4 x8

45000048



Anilha M8x16x1,6

Land Rover Defender
90 TD5 (99-07)



Land Rover Defender
90 TD4 (07-)



5 x4


45000018



Fêmea Frejada M8

6 x2

45000077



Prf. Cb. Sx. M6x25



1



2



3



4



5



6



7



8

